


Thank you for purchasing Wireless Panic Button. With cutting-edge design and elegant appearance, it is easy to carry and use. This button can only be used together with our alarm systems. In case of emergency, the panel will alarm and you will be alerted by SMS or calls.

Connect with Control Panel

This button should be used together with our control panels. It can only work after being connected with the control panel.

1. The control panel should be under the connecting state (please refer to the instructions of each panel)
2. Press the SOS button, the panel beeps once. The connection is successful.

Note: The control panel will beep twice if the panic button has been connected before.



Usage

Press the SOS button when there is an emergency. The alert SMS for emergency will be sent or you will get a phone call from the control panel regardless of the panel state. Then you are able to take actions immediately.

Note: The alarm numbers should be pre-stored in the control panel to get alert SMS or phone call from panel when there is an alarm.

For how to store phone numbers, please refer to the manual of each control panel.

Specifications

Power Supply: DC 3 V (one CR2032 button cell battery)

Alarm Current: < 9.5 mA

Transmitting Distance: < 80 m (in open area)

Radio Frequency: 868 MHz

Housing Material: PC+ABS plastic

Operating Condition:

Temperature 0°C ~ + 55°C

Relative Humidity: < 80% (non-condensing)

Main Body Dimensions (L x W x H): 52 x 54.5 x 10 mm