



Smartphone/Tablet/DSLR Teleprompter

Global patent design Support wide angle lens



Contents

- Packing list
- Structure
- Installation
- Application
- Remote controller
- After-Service
- Warranty card

Packing list



Teleprompter



Smartphone clamp



Smartphone/Tablet clamp



(49/52/55/58/62/67/72/77/82mm)

Lens adapter



Remote controller



Screwdriver + Screw



Foam ring




Microfiber cloth



User manual

Structure


Structure






Structure

Structure





Mount Type: Smartphone + Smartphone





Installation steps

Teleprompter Installation for Smartphone



Packing List



Take down the front and rear cover of the teleprompter.



Take out the phone/tablet clamp and the teleprompter



Tighten the screw with a screwdriver



Assemble the adapter ring with foam on the teleprompter



Put a foam ring on the adapter ring



Takedown the screw of the phone clamp, install the phone clamp on the left or the right hole of the telepromoter.



Put in the gasket and tighten with the screw cap



Install the teleprompter on the stand by the 1/4" screw hole on the bottom of the teleprompter



Install a smartphone on the front and rear of the teleprompter, install finished.

Teleprompter Installation for Tablet



Takedown the screw and phone clamp by the screwdriver,



Rotate the phone clamp to the tablet clamp



Tighten the screw by the screwdriver



Install the teleprompter on the stand, and install foam ring and smartphone, tablet on the teleprompter.

Application

Mount Type

1) Tablet + Camera



2) Smartphone + Camera



Application

Installation steps



Take out the lens adapter



Install the lens adapter on your camera



Install the teleprompter on the camera



Put the smartphone on the teleprompter



Install the whole teleprompter on the tripod



Adjust the focus of lens to full screen

Application



Application

IOS app download



IOS user search"BESTVIEW."

Android app download





Scan the QR code to download the app

Remote controller



Remote controller

Remote use instruction

```
1.power on: Keep press  (about 2 seconds) . 2.power off: Keep press  (about 5 seconds) .
```

Notice: if power on without connect anything, it will power off after 5 minutes; if connected the phone, it will power off after 30 minutes

3.Connect: After power on, LED lights on, auto into compare mode, select BESTVIEW toconnect after connected LED lights off Nøxt time it will connect automaticily.If you want connect new device. on power off mode, keep press €\@\\
longer than 8seconds, lighs flicker, then into the compare mode.





Conditions of Warranty Service

- 1.Free service for one year from the day of purchase if the issue is caused by manufacturing errors.
- 2. The components and maintenance service fee will be charged if the period is expired.

Free service will not be provided in the following situations (* Even if the product is still within the warranty period)

- 1.Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- 2.Damage caused by a natural disaster, abnormal voltage, and environmental factors, etc.

Warranty card

Warranty Card				
User Infomation				
Name:	Phone:			
Add:				
Sales Infomation				
Sale date:				
Distrbutor name:				
Distrbutor tel:				
Repair log				
Repair date:	Repair name:			
Issue:				
Result: 🗆 Repaired 🗆 Not repa	aired Return			

